

# Solid Timber Overlay & Flooring Installation Guide



## Transport, Storage & Handling Procedures

Solid timber flooring should not be transported to a project site during rain, as the product must be placed immediately under permanent cover upon arrival.

If the flooring is stored outdoors and exposed to weather or excessive heat, it can absorb unwanted moisture or become damaged.

Resellers must ensure that buyers understand it is the installer's responsibility to verify that the timber flooring has the correct moisture content before installation.

If the installer has any concerns about the moisture level, they should contact City Timber for guidance before proceeding.

**Install with confidence for  
performance that endures**

## Managing Site Conditions & Installation Environments

Solid timber flooring is produced to an **average moisture content** suitable for a wide range of Australian climates. However, once transported and stored in different regions, the **site conditions** may vary from those at the point of manufacture.

It is therefore the **installer's responsibility** to evaluate the installation environment and determine whether the flooring requires **acclimatisation** before installation.

The installer must be familiar with and correctly apply the **onsite acclimatisation procedure**.

## Installation Requirements - Solid Timber Overlay & Flooring

City Timber requires that all procedures for the **transport, handling and installation** of Stagwood solid timber flooring species be carried out in full compliance with the **current Australian Timber Flooring Association (ATFA) Technical Publication - Solid Timber Flooring Industry Standard**.

